

ESP-WROVER32 AT V1.1.2 20180904 Release Note

Here is a list of AT commands. More details are in documentation

[esp32_at_instruction_set_and_examples_en.pdf](#) or [esp32_at_instruction_set_and_examples_cn.pdf](#).

The ESP32 sends AT commands through UART1 by default, for ESP-WROVER32, it is:

- GPIO19 is RXD
- GPIO22 is TXD
- GPIO14 is RTS
- GPIO15 is CTS

Feature

- Update ESP-IDF to version 3.0.3(054e82b4).

Bug fixes

- Fix an issue that system will crash if too many devices are scanned in BLE.
- Fix an issue that system will crash if an end mark '\r\n' is missed in AT command.

ESP-WROVER32 AT V1.1.1 20180703 Release Note

Bug fix

- Fix bug that ESP32-AT get crushed when been sent AT with 2 "\r\n"

ESP-WROVER32 AT V1.1 20180612 Release Note

BLE AT

Features

- AT+BLESPPCFG : Sets BLE spp parameters
- AT+BLESPP : Enter BLE spp mode
- AT+BLESECPARAM : Set BLE encryption parameters
- AT+BLEENC : Initiate BLE encryption request
- AT+BLEENCRSP : Grant security request access.
- AT+BLEKEYREPLY : Reply the key value to the peer device in the lagecy connection stage.
- AT+BLECONFREPLY : Reply the comfirm value to the peer device in the lagecy connection stage.
- AT+BLEENCDEV : Query BLE encryption device list
- AT+BLEENCCLEAR : Clear BLE encryption device list

Bug fixes

- Fix bug that gatt client exception after disconnect
- Fix gatt Server did not get correct write result code
- Fix gatt cmd will not report error when disconnected
- Fix ble incorrect optional parameter checking
- Fix ble incorrect param type checking
- Fix ble read/write to char/descriptor without permission did not return error
- Fix ble Set ATTR value fail
- Fix ble 128bit uuid crash
- Fix bug that when deinit the ble, do not free gatts list
- Fix ble autoconnect in passthrough mode

Optimizations

- support char write long and add param for multi connection
- support gatts initiate disconnect from client
- support multi conn for server
- update connection param command support gatt server

WiFi AT

Features

- AT+RFPOWER : Set RF TX Power
- AT+CIPSSLCONF : Config SSL client

Bug fixes

- Fix bug that UDP packet loss is serious when transparent transmission

- Fix bug that print error log when startup
- Fix bug restart problem after boot-strap
- Fix bug that reconnect to TCP server twice in passthrough mode
- Fix bug the throughput is very low when uart baudrate is 2000000
- Fix bug that ssl connection doesn't reconnect to server when disconnected
- Fix bug the current is about 77uA after deep sleep
- Fix ping repeatedly cause reboot
- Fix bug It crashes when UART baudrate and mcu mismatch
- Fix bug tcp server will be closed when connections reach max
- Fix bug that crash if the parameter number of AT command is less than `espatgetparaas_digit` parameter number
- Fix bug that it doesnot work when configure server max connection
- Fix bug that it print CLOSED after link disconnect when in transparent transmittion
- Fix bug that remote port is incorrect.
- Fix bug the type of execution command parses error
- Fix Bug that it will reboot after restarting if setting AT+SAVETRANSLINK
- Fix Bug that works bad if delayed among each character when sending command
- Fix bug it crash when smartconfig,if SSID length is 32
- Fix connected UDP display wrong IP
- Fix bug that SSL server accepts fail
- Fix bug that Print 'CONNECT' when ssl connect fail
- Set the range of AT+CWLAPOPT
- Fix bug that Print wifi status when wifi status change
- Fix bug that Sometimes AT+CIPCLOSE cannot return
- Fix bug that TCP doesn't disconnect when WiFi station disconnected
- Fix bug that the static param `conning_flag` was not reset after deinit
- Fix bug that WiFi reconnect after AT+CWQAP
- Fix Delay time is incorrect
- Fix Dns servers change when connecting different AP

Optimizations

- Set Default uart is flow control,and add uart query cmd
- Add AT command line terminator
- Add `espatcustomnetopsregist` in `espat.h` to callback some status about socket
- add query cmd for `blescanparam`
- Add multi-ca support for ssl client
- Add save SSID when using WPS
- Add prefix in the string by AT+CWLIF responded
- Optimize ssl memory in AT module

ESP-WROVER32 AT V1.0 20171117 Release Note

BLE AT

- AT+BLEINIT : Bluetooth Low Energy (BLE) initialization
- AT+BLEADDR : Sets BLE device's address
- AT+BLENNAME : Sets BLE device's name
- AT+BLESCANPARAM : Sets parameters of BLE scanning
- AT+BLESCAN : Enables BLE scanning
- AT+BLESCANRSPDATA : Sets BLE scan response
- AT+BLEADVPARAM : Sets parameters of BLE advertising
- AT+BLEADVDATA : Sets BLE advertising data
- AT+BLEADVSTART : Starts BLE advertising
- AT+BLEADVSTOP : Stops BLE advertising
- AT+BLECONN : Establishes BLE connection
- AT+BLEDISCONN : Ends BLE connection
- AT+BLEDATALEN : Sets BLE data length
- AT+BLECFGMTU : Sets BLE MTU length
- AT+BLEGATTSSRVCRE : Generic Attributes Server (GATTS) creates services
- AT+BLEGATTSSRVSTART : GATTS starts services
- AT+BLEGATTSSRV : GATTS discovers services
- AT+BLEGATTSSCHAR : GATTS discovers characteristics
- AT+BLEGATTSENTFY : GATTS notifies of characteristics
- AT+BLEGATTSSIND : GATTS indicates characteristics
- AT+BLEGATTSSSETATTR : GATTS sets attributes
- AT+BLEGATTCPRIMSRV : Generic Attributes Client (GATTC) discovers primary services
- AT+BLEGATTCCINCLSRV : GATTC discovers included services
- AT+BLEGATTCCCHAR : GATTC discovers characteristics
- AT+BLEGATTCCRD : GATTC reads characteristics
- AT+BLEGATTCCWR : GATTC writes characteristics

System AT

Bug fixes

- Fix a bug that error log is printed when startup
- Fix restart problem after boot-strap
- Fix crash after use hardware AES driver

Optimizations

- AT+FS : fatfs is supported
- Add custom partitions table
- Rename at customize area and add command to operate partition
- Set frequency 80Mhz to reduce power consumption
- Add ESP32 AT custom partitions table
- Add firmware version in AT+GMR
- Change the configuration of UART flow control
- Enable ble in sdkconfig.defaults
- **partition:** Adjust partition table for ble
- Set xtal freq to be 40Mhz by default

WiFi AT

Bug fixes

- Fix a bug that fail to send UDP packet in some cases
- Fix wrong IP format
- Fix error server timeout
- Fix AT+CWQAP shows OK in ap mode
- Fix a bug that system may crash if the SSID length is 32 in smartconfig
- Fix a bug that server timeout does not work for SSL connection in some scenarios
- Fix a bug that "+IPD" is apart from data
- Fix a bug that sometimes AT+CIPCLOSE cannot return

Optimizations

- AT+CWSTARTSMART : Airkiss + ESP-TOUCH
- AT+PING : ping function
- AT+MDNS : mdns function
- AT+CIPSERVERMAXCONN : set the max connections allowed by server
- Add AT+CWMODE=0 to stop WiFi
- Add prefix in the string by AT+CWLIF responded
- Modify the information of query server
- Support more ssl protocol version
- SSL client supports transparent transmission
- Support ssl server and add AT+CIPSERVER? command
- Optimize AT+CIUPDATE to support ssl update
- Add parameter for AT+CIUPDATE to specify ota version
- Configure six sockets by default
- Modify README of tools for AT, and provide ssl cert bin for testing
- Optimize UART-WiFi passthrough mode for autoconnection and UDP transmission

- Optimize smartconfig to save SSID and password into flash
- Optimize SSL connection.

Tools

- Add tool for PKI bin
- Add GATT service bin generation tool

ESP-WROVER32 AT V0.10 20170918 Release Note

This is the first release of ESP32 AT firmware, which supports AT commands through UART.

Basic AT Commands

- AT : Tests AT startup.
- AT+RST : Restarts a module.
- AT+GMR : Checks version information.
- AT+GSLP : Enters Deep-sleep mode.
- ATE : Configures echoing of AT commands.
- AT+RESTORE : Restores the factory default settings of the module.
- AT+UART : UART configuration.
- AT+UART_CUR : Current UART configuration.
- AT+UART_DEF : Default UART configuration, saved in flash.
- AT+SLEEP : Sets the sleep mode.
- AT+SYSRAM : Checks the remaining space of RAM.

Wi-Fi AT Commands

- AT+CWMODE : Sets the Wi-Fi mode (STA/AP/STA+AP).
- AT+CWJAP : Connects to an AP.
- AT+CWLAPOPT : Sets the configuration of command AT+CWLAP.
- AT+CWLAP : Lists available APs.
- AT+CWQAP : Disconnects from the AP.
- AT+CWSAP : Sets the configuration of the ESP32 SoftAP.
- AT+CWLIF : Gets the Station IP to which the ESP32 SoftAP is connected.
- AT+CWDHCP : Enables/disables DHCP.
- AT+CWDHCPS : Sets the IP range of the ESP32 SoftAP DHCP server. Saves the setting in flash.
- AT+CWAUTOCONN : Connects to the AP automatically on power-up.
- AT+CIPSTAMAC : Sets the MAC address of ESP32 Station.
- AT+CIPAPMAC : Sets the MAC address of ESP32 SoftAP.

- AT+CIPSTA : Sets the IP address of ESP32 Station.
- AT+CIPAP : Sets the IP address of ESP32 SoftAP.
- AT+CWSTARTSMART : Starts SmartConfig.
- AT+CWSTOPSMART : Stops SmartConfig.
- AT+WPS : Enables the WPS function.

TCP/IP-Related AT Commands

- AT+CIPSTATUS : Gets the connection status.
- AT+CIPDOMAIN : DNS function.
- AT+CIPSTART : Establishes TCP connection, UDP transmission or SSL connection.
- AT+CIPSEND : Sends data.
- AT+CIPSENDEX : Sends data when length of data is , or when \0 appears in the data.
- AT+CIPCLOSE : Closes TCP/UDP/SSL connection.
- AT+CIFSR : Gets the local IP address.
- AT+CIPMUX : Configures the multiple connections mode.
- AT+CIPSERVER : Deletes/Creates TCP server.
- AT+CIPMODE : Configures the transmission mode.
- AT+SAVETRANSLINK : Saves the transparent transmission link in flash.
- AT+CIPSTO : Sets timeout when ESP32 runs as a TCP server.
- AT+CIUPDATE : Updates the software through Wi-Fi.
- AT+CIPDINFO : Shows remote IP and remote port with +IPD.
- AT+CIPSNTPCFG : Configures the time domain and SNTP server.
- AT+CIPSNTPTIME : Queries the SNTP time.